

**DEMAND**

# Easy-Coat™



## EPS Foam Coating System

**50 LBS.  
(22.7 KG)**

✓ Coats and Bonds to Foam, Metal, Stucco and Wood

✓ No Mesh Required

#EC50W White

#EC50G Grey

### Mixing Instructions —

- Read directions thoroughly before proceeding.
- Each 50-pound bag will generally require 1 to 1.5 gallons of clean water depending on the application.
- It is recommended that a mechanical mixing device be used.
- Start with 3/4 to 1 gallon clean water.
- Add bag of Auto-Coat and mix until Auto-Coat is thoroughly saturated.
- Add the balance of the required water and mix for 5 minutes; be sure that the product is thoroughly mixed.
- Let the blended Easy-Coat sit for 5 minutes, then remix to break the set before any application.

### Machine Extrusion Applications —

- Follow procedure for normal mixing instructions, but after Auto-Coat is mixed, let it sit for 10 minutes then remix to break set.
- You must obtain a creamy consistency for proper machine applied application.
- When coatings over 3/16" are desired, 2 coats may be required allowing first coat to dry before second coat is applied.
- All coated shapes should be moist cured and allowed to dry in a shaded non-windy area.

### SURFACE COATING

- Auto-Coat should be applied with a coating of 3/16" to 1/4" thick to the foam shapes, and can be applied either by a machine or by hand.

### CLEAN UP

- Immediately clean all tools and mixing equipment with water after use.

### COVERAGE

- One 50-pound bag will cover approximately 40–60 sq. feet (includes coating and adhesion).

### Other Applications —

- When adhesion is desired over any surface a test piece should be placed in position and examined after 24 hours to insure proper adhesion.
- When using Easy-Coat as an adhesive, it should be mixed to a semi-paste like consistency.
- Dampen the substrate, apply approximately 1/4" of Easy-Coat to the entire back surface of the foam shape.
- Set the foam shape into position (over the desired substrate), press evenly over the the entire foam shape to secure bond. Normally this will be sufficient to hold the shape in place.
- On larger shapes, it may be necessary to provide additional support.
- Easy-Coat must be applied to all butt joints. A 2" Fiberglass mesh joint tape should be used on all joints.
- You may apply stucco products after the surface has cured.

### SAFETY

Contains Portland cement. Wear rubber gloves and eye protection. Avoid eye contact or prolonged contact with skin. If eye contact occurs, flush with water for 15 minutes. Consult physician immediately. This product contains free silica. Do not breathe dust; wear NIOSH approved respirator. KEEP OUT OF REACH OF CHILDREN. DO NOT TAKE INTERNALLY.

### DISCLAIMER OF WARRANTY

Demand Products, Inc. is making no recommendation for the use and purpose for which this product may be utilized. No guarantee of results are made as the conditions of installation are beyond our control. No representations or warranties, either express or implied, are made with respect to this product and its uses beyond the description on the face hereof, and in particular there are no implied warranties of merchantability or fitness for a particular purpose. Under no circumstances will Demand Products, Inc. be liable for consequential damages, or any damages in excess of the purchase price of this product.

### WARNING

Demand Products, Inc., as blender of processed material in the State of California, we are required by Proposition 65 to warn that one or more of the components in this product, contains chemicals known to the State of California, to cause cancer, birth defects, or other reproductive.

Distributed by:  
**Demand Products, Inc.**  
1055 Nine North Dr. • Alpharetta, GA 30004 USA  
1-800-325-7540